dCS Rossini Transport Menu Guide

The STEP > button moves along the menu, the STEP < button moves back.
Press the MENU button to set a menu option or change options.

MENU

Information	**Unit Status**	**Version**	**Contact**	**Update**
	Displays the unit status.	Displays the software issues.	Displays dCS contact details.	Loads new software from a dCS update disc.
Unit Settings	**Layer**	**PCM Enable**	**Upsample**	**RS232 Mode**
	Selects the format for playing hybrid discs (CD/SACD).	Turns the PCM outputs on / off.	Upsamples CD data to DSD, DSD/2 or DXD on AES1+2.	Select RS232 Text Mode or Binary Mode.
Config	**Lock**	**Save**	**Restore**	**Factory Reset**
	Locks some important settings.	Saves the current config to memory.	Loads the previously saved config from memory.	Restores standard factory settings.
Display Settings	**Brightness**	**Display On/Off**	**Logo**	
	Sets the display brightness.	Turns the main display on/off.	Turns the dCS Logo illumination on/off	
Signal Generator	**Channel Check**	**Phase Check**	**Burn In**	
	Outputs tone on L channel only then R channel only.	Outputs noise on both channels then inverts R.	Outputs modulated pink noise to burn-in your system.	